

nook®


by Barnes & Noble

Quick Start Guide

nook®

by Barnes & Noble

Use this Quick Start Guide
to learn the NOOK® basics.



Or tap or swipe right or left to turn the page

home

Here you'll be able to access what you're reading now and what you're reading next based on personalized recommendations.


Tap to return to your last read



Tap to return to your latest book

reading tools

Use reading tools to change fonts and sizes, jump to a particular page or search for your favorite phrase.




text tools

Change fonts and sizes.

Change
font style

Change
text size



explore

Use the quick nav bar to get around and explore your NOOK. Just tap where you want to go next.



Press the "n" button to show or hide

library

Find and manage all of your books, magazines and newspapers.

Tap to filter and sort all your reads



Tap to read and double tap to view details

shop

Shop your NOOK Store™ and get personalized recommendations from expert booksellers.

Tap to browse all popular lists & categories



Tap to see more offers & recommendations

wake up & unlock

When your NOOK goes to sleep, press the “n” button to wake it up. Then drag right to unlock.



Drag right
to unlock

Press the “n” button to wake up NOOK

ready for more?

There's a lot to explore on
your Simple Touch Reader™.

Plus, over 2 million books,
magazines and newspapers,
right at your fingertips.

Welcome to NOOK.